

Link do produktu: <https://www.androla.pl/bateria-sony-vgp-bpl13-vgp-mps13-vgp-mps21-4400mah-p-9553.html>



Bateria Sony VGP-BPL13 VGP-BPS13 VGP-BPS21 4400mAh

Dostępność	Zapytaj o dostępność
Czas wysyłki	24 godziny
Numer katalogowy	09344
Kod producenta	BL171
Producent	Brak

Opis produktu

Akumulator do laptopów Sony VGP-BPL13/VGP-BPS13/VGP-BPS21/VGN-FW 4400mAh

Specyfikacja techniczna

Producent laptopa: SONY
Napięcie: 11.1V (pełna zgodność z 10.8V)
Pojemność: 4400 mAh
Ilość ogniw: 6
Kolor: czarny
Waga: 302 g
Typ: Li-ion

Zamiennik następujących akumulatorów

VGP-BPL13, VGP-BPL13A, VGP-BPL13B, VGP-BPL13/B, VGP-BPS13, VGP-BPS13A, VGP-BPS13/A, VGP-BPS13AB, VGP-BPS13A/B, VGP-BPS13A/R, VGP-BPS13A/Q, VGP-BPS13B, VGP-BPS13/B, VGP-BPS13B/B, VGP-BPS13B/Q, VGP-BPS21, VGP-BPS21A

Przeznaczony do następujących notebooków:

SONY VAIO:

VGN-AW110J, VGN-AW110J/H, VGN-AW110N, VGN-AW110N/H, VGN-AW11M/H, VGN-AW120J, VGN-AW120J/H, VGN-AW125, VGN-AW125J/H, VGN-AW130J, VGN-AW130J/H, VGN-AW150, VGN-AW150Y, VGN-AW150Y/H, VGN-AW160J, VGN-AW160J/Q, VGN-AW170Y, VGN-AW170Y/Q, VGN-AW180Y, VGN-AW180Y/Q, VGN-AW190, VGN-AW11M/H, VGN-AW11S/B, VGN-AW11XU/Q, VGN-AW11Z/B, VGN-AW170C, VGN-AW19, VGN-AW19/Q, VGN-AW21M/H, VGN-AW21S/B, VGN-AW21VY/Q, VGN-AW21XY/Q, VGN-AW21Z/B, VGN-AW230J/H, VGN-AW235J/B, VGN-AW270Y/Q, VGN-AW27GY/QE1, VGN-AW290JFQ, VGN-AW31M/H, VGN-AW31S/B, VGN-AW31XY/Q, VGN-AW31ZJ/B, VGN-AW35GJH, VGN-AW37GY/HE1, VGN-AW37GYQ, VGN-AW41JF, VGN-AW41JF/H, VGN-AW41MF, VGN-AW41MF/H, VGN-AW41XH, VGN-AW41XH/Q, VGN-AW41ZF, VGN-AW41ZF/B, VGN-AW50DB/H, VGN-AW51JGB, VGN-AW52JGB, VGN-AW53FB, VGN-AW70B/Q, VGN-AW71JB, VGN-AW72JB, VGN-AW73FB, VGN-AW80NS, VGN-AW80S, VGN-AW80US, VGN-AW81DS, VGN-AW81JS, VGN-AW81YS, VGN-AW82DS, VGN-AW82JS, VGN-AW82YS, VGN-AW83FS, VGN-AW83GS, VGN-AW83HS, VGN-AW90NS, VGN-AW90S, VGN-AW90US, VGN-AW91CDS, VGN-AW91CJS, VGN-AW91CYS, VGN-AW91DS, VGN-AW91JS, VGN-AW91YS, VGN-AW92CDS, VGN-AW92CJS, VGN-AW92CYS, VGN-AW92DS, VGN-AW92JS, VGN-AW92YS, VGN-AW93FS, VGN-AW93GS, VGN-AW93HS, VGN-AW93ZFS, VGN-AW93ZGS, VGN-AW93ZHS, , , VGN-BZ11EN, VGN-BZ11MN, VGN-BZ11VN, VGN-BZ11XN, VGN-BZ12EN, VGN-BZ12VN, VGN-BZ12XN, VGN-BZ13VN, VGN-BZ13XN, VGN-BZ153N, VGN-BZ15GN, VGN-BZ16GN, VGN-BZ21VN, VGN-BZ21XN, VGN-BZ31VT, VGN-BZ31XT, VGN-BZ560CTO, VGN-BZ560N22, VGN-BZ560N24, VGN-BZ560N26, VGN-BZ560N30, VGN-BZ560N32, VGN-BZ560N34, VGN-BZAAFS, VGN-BZAAHS, VGN-BZAAANS, VGN-BZAAPS, , , VGN-CS11S/P, VGN-CS11S/Q, VGN-CS11S/W, VGN-CS11Z/R, VGN-CS11Z/T, VGN-CS13H/P, VGN-CS13H/Q, VGN-CS13H/R, VGN-CS13H/W, VGN-CS13T/W, VGN-CS16T/P, VGN-CS16T/R, VGN-CS16T/T, VGN-CS16T/W, VGN-CS17H/Q, VGN-CS17H/W, VGN-CS19/P, VGN-CS19/Q, VGN-CS19/R, VGN-CS19/W, VGN-CS19JTP, VGN-CS19JTPQ, VGN-CS19JTR, VGN-CS19JTT, VGN-CS19JTW, VGN-CS21S/J, VGN-CS21S/JR, VGN-CS21S/P, VGN-CS21S/R, VGN-CS21S/T, VGN-CS21S/V, VGN-CS21S/W, VGN-CS21Z/Q, VGN-CS220DP, VGN-CS220DQ, VGN-CS220DR, VGN-CS220DT, VGN-CS220DW, VGN-CS230J/Q, VGN-CS23H, VGN-CS23H/B, VGN-CS23H/S, VGN-CS23T/Q, VGN-

CS23T/W, VGN-CS25H, VGN-CS25H/C, VGN-CS25H/P, VGN-CS25H/Q, VGN-CS25H/R, VGN-CS25H/W, VGN-CS260DQ, VGN-CS260DW, VGN-CS26GW, VGN-CS26T/C, VGN-CS26T/P, VGN-CS26T/Q, VGN-CS26T/R, VGN-CS26T/T, VGN-CS26T/V, VGN-CS26T/W, VGN-CS27, VGN-CS27/C, VGN-CS27/P, VGN-CS27/R, VGN-CS27/W, VGN-CS28, VGN-CS28/Q, VGN-CS290JEC, VGN-CS290JEP, VGN-CS290JEQ, VGN-CS290JER, VGN-CS290JEW, VGN-CS2CN1, VGN-CS31S/P, VGN-CS31S/R, VGN-CS31S/T, VGN-CS31S/V, VGN-CS31S/W, VGN-CS31Z/Q, VGN-CS33H, VGN-CS33H/B, VGN-CS33H/Z, VGN-CS35GNB, VGN-CS36G/C, VGN-CS36G/I, VGN-CS36G/P, VGN-CS36G/Q, VGN-CS36G/R, VGN-CS36G/T, VGN-CS36G/U, VGN-CS36G/W, VGN-CS36G/J, VGN-CS36H, VGN-CS36H/C, VGN-CS36H/P, VGN-CS36H/Q, VGN-CS36H/R, VGN-CS36H/W, VGN-CS36TJ/C, VGN-CS36TJ/J, VGN-CS36TJ/P, VGN-CS36TJ/Q, VGN-CS36TJ/R, VGN-CS36TJ/T, VGN-CS36TJ/U, VGN-CS36TJ/V, VGN-CS36TJ/W, VGN-CS39, VGN-CS39/J, VGN-CS39/U, VGN-CS390JDV, VGN-CS50B/W, VGN-CS51B/W, VGN-CS52JB/W, VGN-CS60B/P, VGN-CS60B/Q, VGN-CS60B/R, VGN-CS61B/P, VGN-CS61B/Q, VGN-CS61B/R, VGN-CS62JB/P, VGN-CS62JB/Q, VGN-CS62JB/R, VGN-CS71B/W, VGN-CS72JB/W, VGN-CS90HS, VGN-CS90NS, VGN-CS90S, VGN-CS91HS, VGN-CS91NS, VGN-CS91S, VGN-CS92DS, VGN-CS92JS, VGN-CS92XS, , , VGN-FW130EW, VGN-FW130NW, VGN-FW139E/H, VGN-FW139EH, VGN-FW139NW, VGN-FW140EH, VGN-FW140EW, VGN-FW140NW, VGN-FW145E/W, VGN-FW145EW, VGN-FW150EW, VGN-FW160EH, VGN-FW170JH, VGN-FW180EH, VGN-FW190EBH, VGN-FW190EDH, VGN-FW198UH, VGN-FW21E, VGN-FW21J, VGN-FW21L, VGN-FW21M, VGN-FW21Z, VGN-FW25T/B, VGN-FW26T/B, VGN-FW27/B, VGN-FW27/W, VGN-FW27T/H, VGN-FW29/B, VGN-FW290JRB, VGN-FW290JTB, VGN-FW290JTH, VGN-FW290JTW, VGN-FW290JVH, VGN-FW30B, VGN-FW31M, VGN-FW31ZJ, VGN-FW32J, VGN-FW33G/W, VGN-FW33GW, VGN-FW340DW, VGN-FW340J/H, VGN-FW350DH, VGN-FW355J/H, VGN-FW35F, VGN-FW35F/B, VGN-FW35F/W, VGN-FW35TJ/B, VGN-FW36TJ/B, VGN-FW373DW, VGN-FW378DH, VGN-FW378J/B, VGN-FW37J, VGN-FW37J/B, VGN-FW41E/H, VGN-FW41J/H, VGN-FW41M/H, VGN-FW41ZJ/H, VGN-FW45GJB, VGN-FW45TJ/B, VGN-FW465J/B, VGN-FW46GJ/BE1, VGN-FW46GJB, VGN-FW47GYH, VGN-FW50B, VGN-FW51B/W, VGN-FW51MF, VGN-FW51MF/H, VGN-FW51ZF, VGN-FW51ZF/H, VGN-FW52JB, VGN-FW54FB, VGN-FW70DB, VGN-FW71DB/W, VGN-FW72JGB, VGN-FW73JGB, VGN-FW74FB, VGN-FW81HS, VGN-FW81NS, VGN-FW81S, VGN-FW82DS, VGN-FW82JS, VGN-FW82XS, VGN-FW83DS, VGN-FW83JS, VGN-FW83XS, VGN-FW90HS, VGN-FW90NS, VGN-FW90S, VGN-FW91NS, VGN-FW91S, VGN-FW92DS, VGN-FW92JS, VGN-FW93DS, VGN-FW93JS, VGN-FW93XS, VGN-FW94FS, VGN-FW94GS, VGN-FW94HS, VGN-NS11M/S, VGN-NS11S/S, VGN-NS12M/W, VGN-NS15G/S, VGN-NS15H/S, VGN-NS190J/S, VGN-NS190J/W, VGN-NS21M/P, VGN-NS21M/W, VGN-NS21S/S, VGN-NS21S/W, VGN-NS21Z/S, VGN-NS230DP, VGN-NS230DW, VGN-NS235J/L, VGN-NS235J/P, VGN-NS235J/S, VGN-NS235J/W, VGN-NS240DP, VGN-NS240DS, VGN-NS240DW, VGN-NS255DS, VGN-NS25G/E1, VGN-NS25G/P, VGN-NS25G/S, VGN-NS25GP, VGN-NS290J/S, VGN-NS31M/P, VGN-NS31M/W, VGN-NS31S/S, VGN-NS50B/L, VGN-NS50B/W, VGN-NS51B/L, VGN-NS51B/P, VGN-NS51B/W, VGN-NS52JB/L, VGN-NS52JB/P, VGN-NS52JB/W, VGN-NS70B/W, VGN-NS71B/W, VGN-NS72JB/W, VGN-NS90HS, VGN-NS92JS, VGN-NS92XS

VGN-NW130J/T, VGN-NW21EF/S, VGN-NW21JF, VGN-NW21MF, VGN-NW21MF/W, VGN-NW21ZF, VGN-NW31EF/W, VGN-NW31JF, VGN-NW320F/B, VGN-NW320F/TC, VGN-NW35E, VGN-NW35E/B, VGN-NW35E/P, VGN-NW35E/W, VGN-NW380F/S, VGN-NW380F/T, VGN-NW50JB, VGN-NW51FB/N, VGN-NW51FB/W, VGN-NW70JB, VGN-NW71FB/N, VGN-NW71FB/W, VGN-NW91FS, VGN-NW91GS, VGN-NW91VS

VGN-SR11M, VGN-SR12G/B, VGN-SR12G/P, VGN-SR12G/S, VGN-SR130EB, VGN-SR130EP, VGN-SR130ES, VGN-SR130NB, VGN-SR13GN/B, VGN-SR13GN/P, VGN-SR13GN/S, VGN-SR140E/S, VGN-SR140EB, VGN-SR140EP, VGN-SR140ES, VGN-SR140NS, VGN-SR150FN, VGN-SR165E/B, VGN-SR165E/P, VGN-SR165E/S, VGN-SR165EB, VGN-SR165EP, VGN-SR165ES, VGN-SR165NB, VGN-SR175N/B, VGN-SR175NB, VGN-SR190EBJ, VGN-SR190EBQ, VGN-SR190F, VGN-SR19VN, VGN-SR19XN, VGN-SR21M/S, VGN-SR220J/B, VGN-SR220J/H, VGN-SR23H/B, VGN-SR240J/B, VGN-SR240N/B, VGN-SR25G/B, VGN-SR25G/P, VGN-SR25G/S, VGN-SR25M/B, VGN-SR25S/B, VGN-SR25T/P, VGN-SR25T/S, VGN-SR26/B, VGN-SR26/P, VGN-SR26/S, VGN-SR26GN/B, VGN-SR26MN/B, VGN-SR27TN/B, VGN-SR28/B, VGN-SR28/J, VGN-SR28/Q, VGN-SR290JTH, VGN-SR290JTJ, VGN-SR290JTQ, VGN-SR290JVB/C, VGN-SR290JVH/C, VGN-SR290NTB, VGN-SR29VN/S, VGN-SR29XN/S, VGN-SR31M/S, VGN-SR33H, VGN-SR33H/B, VGN-SR33H/P, VGN-SR33H/S, VGN-SR35G/B, VGN-SR35G/E1, VGN-SR35G/P, VGN-SR35G/S, VGN-SR35M/B, VGN-SR35T/B, VGN-SR35T/P, VGN-SR35T/S, VGN-SR36GNS, VGN-SR36MN/B, VGN-SR36MN/P, VGN-SR37TN/B, VGN-SR38, VGN-SR38/B, VGN-SR38/J, VGN-SR38/Q, VGN-SR390NAB, VGN-SR390NAH, VGN-SR39D, VGN-SR39D/J, VGN-SR39D/Q, VGN-SR39VN/S, VGN-SR39XN/S, VGN-SR3CW/B, VGN-SR3S1, VGN-SR41M/P, VGN-SR41M/S, VGN-SR41M/W, VGN-SR43G/B, VGN-SR43G/N, VGN-SR43G/P, VGN-SR43G/W, VGN-SR43S/B, VGN-SR43S/P, VGN-SR45G/G, VGN-SR45G/N, VGN-SR45G/P, VGN-SR45H, VGN-SR45H/B, VGN-SR45H/N, VGN-SR45H/P, VGN-SR45M/B, VGN-SR45M/P, VGN-SR45T/B, VGN-SR45T/P, VGN-SR45T/W, VGN-SR46GD, VGN-SR46GD/B, VGN-SR46GD/P, VGN-SR46GDB, VGN-SR46MD/B, VGN-SR46SD/B, VGN-SR46SD/P, VGN-SR46TD/B, VGN-SR48J, VGN-SR48J/B, VGN-SR48J/J, VGN-SR490JCN, VGN-SR49D, VGN-SR49D/J, VGN-SR49D/Q, VGN-SR49VN/H, VGN-SR51B/P, VGN-SR51B/S, VGN-SR51MF, VGN-SR51MF/W, VGN-SR53GF/B, VGN-SR53GF/N, VGN-SR53GF/P, VGN-SR53GF/W, VGN-SR53SF/B, VGN-SR53SF/P, VGN-SR55GF/B, VGN-SR55GF/N, VGN-SR55GF/P, VGN-SR55MF/B, VGN-SR55TF/B, VGN-SR56GG/B, VGN-SR56GG/S, VGN-SR56MG/B, VGN-SR56SG/B, VGN-SR56SG/P, VGN-SR59VG, VGN-SR59VG/H, VGN-SR70B/S, VGN-SR72B/P, VGN-SR72B/S, VGN-SR73JB/S, VGN-SR74FB/S, VGN-SR90FS, VGN-SR90NS, VGN-SR90S, VGN-SR90US, VGN-SR91NS, VGN-SR91PS, VGN-SR91S, VGN-SR91US, VGN-SR92NS, VGN-SR92PS, VGN-SR92S, VGN-SR92US, VGN-SR93DS, VGN-SR93JS, VGN-SR93PS, VGN-SR93YS, VGN-SR94FS, VGN-SR94GS, VGN-SR94HS, VGN-SR94VS

VPC-YB29KJ/S, VPC-B119GJ/B, VPC-B11AGJ, VPC-B11AVJ, VPC-B11V9E, VPC-B11X9E

VPC-CW12EN/BU, VPC-CW12ES/BU, VPC-CW13EG/BU, VPC-CW13FX/R, VPC-CW152C, VPC-CW152C/B, VPC-CW152C/W, VPC-CW15EC/BU, VPC-CW15EC/WU, VPC-CW15FA/B, VPC-CW15FA/P, VPC-CW15FA/W, VPC-CW15FG/B, VPC-CW15FG/P, VPC-CW15FG/W, VPC-CW15FN/R, VPC-CW16EC/B, VPC-CW16EC/L, VPC-CW16EC/P, VPC-CW16EC/R, VPC-CW16EC/W, VPC-CW16FA/B, VPC-CW16FA/L, VPC-CW16FA/P, VPC-CW16FA/R, VPC-CW16FA/W, VPC-CW16FG/B, VPC-CW16FG/L, VPC-CW16FG/P, VPC-CW16FG/R, VPC-CW16FG/W, VPC-CW18FC/B, VPC-CW18FC/L, VPC-CW18FC/P, VPC-CW18FC/R, VPC-CW18FC/W, VPC-CW18FG/B, VPC-CW18FJ/P, VPC-CW18FJ/R, VPC-CW18FJ/W, VPC-CW19FJ/W, VPC-CW1AFJ, VPC-CW1AGG/B, VPC-CW1AHJ, VPC-CW1BGN/BU, VPC-CW1FFX/L,

VPC-CW1S1E, VPC-CW1S1E/B, VPC-CW1S1E/L, VPC-CW1S1E/P, VPC-CW1S1E/R, VPC-CW1S1E/W, VPC-CW1ZEG/BU, VPC-CW1ZEH/BU, VPC-CW21FX/B, VPC-CW21FX/L, VPC-CW21FX/R, VPC-CW21FX/W, VPC-CW26EC, VPC-CW26EC/B, VPC-CW26EC/P, VPC-CW26EC/W, VPC-CW26FA/B, VPC-CW26FA/L, VPC-CW26FA/P, VPC-CW26FA/R, VPC-CW26FA/W, VPC-CW26FG/B, VPC-CW26FG/L, VPC-CW26FG/P, VPC-CW26FG/R, VPC-CW26FG/W, VPC-CW26FH/B, VPC-CW26FH/L, VPC-CW26FH/P, VPC-CW26FH/R, VPC-CW26FH/W, VPC-CW26FX/B, VPC-CW28EC, VPC-CW28EC/B, VPC-CW28EC/L, VPC-CW28EC/P, VPC-CW28EC/R, VPC-CW28EC/W, VPC-CW28FG/B, VPC-CW28FJ/P, VPC-CW28FJ/R, VPC-CW28FJ/W, VPC-CW29FJ/W, VPC-CW2AFJ, VPC-CW2AGG/B, VPC-CW2AHJ, VPC-CW2BGN/BU, VPC-CW2MFX/PU, VPC-CW2S1E, VPC-CW2S1E/B, VPC-CW2S1E/L, VPC-CW2S1E/P, VPC-CW2S1E/R, VPC-CW2S1E/W, VPC-CW2S5C, VPC-CW2S5C CN1, VPC-CW2Z1E/B

VPC-F112FX/B, VPC-F115FG/B, VPC-F116FGBI, VPC-F117FJ/W, VPC-F117HG/BI, VPC-F118FJ/W, VPC-F119FC, VPC-F119FC/BI, VPC-F119FJ/BI, VPC-F11AFJ, VPC-F11AGJ, VPC-F11AHJ, VPC-F11JFX/B, VPC-F11M1E, VPC-F11M1E/H, VPC-F11MFX/B, VPC-F11S1E, VPC-F11S1E/B, VPC-F11Z1E, VPC-F11Z1E/BI, VPC-F11ZHJ

VPC-F127FJ/W, VPC-F127HGBI, VPC-F128FJ/B, VPC-F129FJ/BI, VPC-F12AFJ, VPC-F12AGJ, VPC-F12AHJ, VPC-F12E1E/W, VPC-F12M1E/H, VPC-F12S1E/B, VPC-F12Z1E/BI

VPC-F135FG, VPC-F135FG/B, VPC-F136FG/BI, VPC-F137HG/BI, VPC-F138FC/BI, VPC-F138FJ/B, VPC-F139FJ/BI, VPC-F13AFJ, VPC-F13AGJ, VPC-F13AHJ, VPC-F13E1E/H, VPC-F13E8E/H, VPC-F13J0E/H, VPC-F13L8E/H, VPC-F13M0E/B, VPC-F13M1E/H, VPC-F13M8E/B, VPC-F13S1E/B, VPC-F13S8E/B, VPC-F13Z0E/B, VPC-F13Z1E/B, VPC-F13Z8E/BI, VPC-F13ZHJ, VPC-F148FJ/B, VPC-F149FJ/BI, VPC-F14AFJ, VPC-F14AGJ, VPC-F14AHJ, VPC-F14ZHJ

VPC-F217HG, VPC-F217HG/BI, VPC-F219FC, VPC-F219FC/BI, VPC-F219FJ/BI, VPC-F21AFJ, VPC-F21AGJ, VPC-F21AHJ, VPC-F21Z1E, VPC-F21Z1E/BI, VPC-F21ZHJ, VPC-F226FJ/S, VPC-F227FJ/B, VPC-F229FJ/BI, VPC-F22AJ, VPC-F22J1E, VPC-F22L1E, VPC-F22M1E, VPC-F22S1E/B

VPC-M125AG/L, VPC-M125AG/P, VPC-M125AG/W, VPC-M125AGP, VPC-M125JC/W, VPC-M126AA/L, VPC-M126AA/P, VPC-M126AA/W, VPC-M126AG/L, VPC-M126AG/P, VPC-M126AG/W, VPC-M126AH/L, VPC-M126AH/P, VPC-M126AH/W, VPC-M128JC/L, VPC-M128JC/P, VPC-M129AJ/L, VPC-M129AJ/P, VPC-M129AJ/W, VPC-M13M1E/L, VPC-M13M1E/P, VPC-M13M1E/W

VPC-S111FM/S, VPC-S115EC, VPC-S115FG, VPC-S117GG, VPC-S117GGB, VPC-S118EC, VPC-S119FJ/B, VPC-S119GC, VPC-S11AFJ, VPC-S11AGJ, VPC-S11AHJ, VPC-S11AVJ, VPC-S11J7E/B, VPC-S11M1E/W, VPC-S11V9E, VPC-S11V9E/B, VPC-S11X9E/B

VPC-S123FGB, VPC-S125EC, VPC-S128EC, VPC-S129FJ/B, VPC-S129FJ/S, VPC-S129GC, VPC-S12AFJ, VPC-S12AGJ, VPC-S12AHJ, VPC-S12AVJ, VPC-S12C7E/B, VPC-S12J1E/W, VPC-S12L9E/B, VPC-S12V9E/B, VPC-S12X9E/B

VPC-S133GN/B, VPC-S135EC, VPC-S135EC/B, VPC-S135EC/G, VPC-S135EC/P, VPC-S135FA/B, VPC-S135FG/W, VPC-S135FH/P, VPC-S136EC, VPC-S136EC/B, VPC-S136EC/G, VPC-S136EC/P, VPC-S136FA/B, VPC-S136FG/B, VPC-S137GA/B, VPC-S137GF/B, VPC-S137GG/B, VPC-S137GH/B, VPC-S138EC, VPC-S138EC/B, VPC-S138EC/G, VPC-S138EC/P, VPC-S139FJ/B, VPC-S139FJ/P, VPC-S139FJ/S, VPC-S139GC, VPC-S139GC/B, VPC-S13AFG/B, VPC-S13AFG/G, VPC-S13AFG/P, VPC-S13AFG/W, VPC-S13AFH/B, VPC-S13AFH/W, VPC-S13AFJ, VPC-S13AGJ, VPC-S13AHJ, VPC-S13L8E/B, VPC-S13L9E/B, VPC-S13M1E, VPC-S13V9E/B, VPC-S13X9E/B

VPC-S149FJ/B, VPC-S149FJ/P, VPC-S149FJ/S, VPC-S14AFJ, VPC-S14AGJ, VPC-S14AHJ

VPC-Y115FG/S, VPC-Y115FGS, VPC-Y115FX/BI, VPC-Y115FXBI, VPC-Y118EC, VPC-Y118GX/BI, VPC-Y119FJ/S, VPC-Y11AFJ, VPC-Y11AGJ, VPC-Y11AHJ, VPC-Y11AVJ, VPC-Y11M1E/S, VPC-Y11S1E, VPC-Y11V9E/S, VPC-Y218EC/BI, VPC-Y218EC/G, VPC-Y218EC/L, VPC-Y218EC/P, VPC-Y218EC/R, VPC-Y219FJ/S, VPC-Y21AFJ, VPC-Y21AGJ, VPC-Y21AHJ, VPC-Y21AVJ, VPC-Y21S1E/G, VPC-Y21S1E/L, VPC-Y21S1E/P, VPC-Y21S1E/SI, VPC-Y22Z5008B

VPC-YA15EC/B, VPC-YA15EC/R, VPC-YA15FG, VPC-YA15FG/B, VPC-YA15FG/R, VPC-YA15FH/B, VPC-YA15FH/R, VPC-YA16EC/B, VPC-YA16EC/R, VPC-YA17GG/B, VPC-YA17GG/R, VPC-YA17GH/B, VPC-YA17GH/R, VPC-YA19FJ/B, VPC-YA1C5E, VPC-YA1V9E, VPC-YA2AJ

VPC-YB15AG/G, VPC-YB15AG/P, VPC-YB15AG/S, VPC-YB15AH/G, VPC-YB15AH/P, VPC-YB15AH/S, VPC-YB16KG/G, VPC-YB16KG/P, VPC-YB16KG/S, VPC-YB19KJ/G, VPC-YB19KJ/P, VPC-YB19KJ/S, VPC-YB1S1E, VPC-YB29KJ/G, VPC-YB29KJ/P, VPC-YB2M1E

VGN-FW11M, VGN-FW139E/H, VGN-FW145E/W, VGN-FW17, VGN-FW17/B, VGN-FW17W, VGN-FW19, VGN-FW19/B, VGN-FW190EBH, VGN-FW190EDH, VGN-FW198U

VGN-SR13, VGN-SR13/B, VGN-SR16, VGN-SR16/P, VGN-SR16/S, VGN-SR18/J, VGN-SR18/J, VGN-SR18/Q

VAIO FW Seria
VAIO SR Seria

Akumulator oryginalnie zapakowany w folię antystatyczną, zabezpieczony gąbką w kartonie

Stan: Nowy